

APPLICATION NOTE

# Mako U Triggering Concept

Mako U cameras were discontinued in December 2020.

V2.0.0 2024-Oct-10

## Scope of this document

This document describes triggering basics **for Mako U** cameras, from best-practice rules to general examples.



#### Triggering with ALvium USB cameras

Please see the Alvium USB Cameras User Guide at www.alliedvision.com/en/ support/technical-documentation/alvium-usb-documentation.



#### Additional information for Mako U cameras

For the Mako U Technical Manual and the Mako U Cameras Features Reference, see www.alliedvision.com/en/support/technical-documentation/ mako-u-documentation.



#### Features usage in programming

For information on programming with features, see the *Vimba Viewer Guide*, included in **Vimba**. See: https://www.alliedvision.com/software.

## Trigger signal flow

The following diagram shows the exposure of a frame started by an external signal. High levels show the active state of a signal. Proportions and dependencies are simplified to show the basic signal flow. Signal 1 starts Cycle 1.




Figure 1: Trigger signal flow



Term	Description
External signal	Electrical trigger signal starting the signal flow
ExposureActive	Exposing a frame
ReadoutActive	Reading out a frame, high when the image sensor is reading out data
FrameTriggerWait	Waiting for a trigger
AcquisitionActive	<ul> <li>Acquiring of frames, needs to be high to start triggering</li> <li>High when the camera image sensor is either exposing, reading out data, or waiting for a trigger</li> </ul>

Table 1: Trigger signal flow, legend

## Trigger latency

Trigger latency is the time delay between the FrameStart trigger and the start of exposure. Trigger latency consists of:

- Jitter and delay of *ExposureStart*
- TriggerDelay

Term	Description
<i>ExposureStart</i> jitter	<ul><li>Deviation from the average periodical signal time</li><li>Time range mainly caused by sensor line synchronization</li></ul>
<i>ExposureStart</i> delay	<ul><li>Deviation from the average periodical signal time</li><li>Time range caused by camera internal timing</li></ul>
TriggerDelay	Value set by the user to extend the trigger latency

Table 2: Trigger latency -> Components

## Best practice rules for triggering

- Set the trigger to *RisingEdge* for fastest possible reaction time.
- Set the trigger pulse width in the supported range.
- Consider that the end of exposure triggers the next readout.
- Make sure the exposure of a frame ends after the readout of the previous frame.
- Start exposure only between the readouts of two lines.
- Consider that *ExposureStart* delay = readout time ExposureTime.

## Triggering when ReadoutActive is low

Apply *FrameStart* trigger when *ReadoutActive* is low. This way, you keep trigger latency (including *ExposureStart* jitter) short.

## Triggering when ReadoutActive is high

For fastest triggering cycle time with simultaneous exposure and readout, apply *FrameStart* trigger immediately when *FrameTriggerWait* is high. Because exposure must always begin at sensor line synchronization, the *ExposureStart* jitter can be up to 1 line cycle.



## Examples

## AcquisitionStart trigger and FrameStart trigger

### AcquisitionStart description

To acquire images, *AcquisitionActive* must be high. Even to trigger the start of an acquisition by a pulse through an I/O, you have to issue an AcquisitionStart command.

AcquisitionStart ();

Figure 2: TriggerMode = Off, software command: AcquisitionStart




Figure 3: TriggerMode = On, software command: AcquisitionStart



#### AcquisitionStop

AcquisitionStop is mandatory to end acquisition.

With AcquisitionMode = *SingleFrame* or *MultiFrame*:

If no AcquisitionStop is signaled, after the selected number of frames has been acquired, the camera internally creates an AcquisitionStop command; this turns AcquisitionActive to low.



## AcquisitionStart trigger and FrameStart trigger dependencies

Figure 4 shows the dependencies between AcquisitionStart and *FrameStart* trigger.




Figure 4: Dependencies of AcquisitionStart and FrameStart

## Modes for triggering

The following sections describe in general the main modes for triggering:

- TriggerMode
- AcquisitionMode
- ExposureMode



## TriggerSelector

The TriggerSelector examples in this section show triggering with AcquisitionMode = *Continuous*.

AcquisitionMode	TriggerSelector		
	AcquisitionStart	FrameStart	
Continuous	Off	Off	
Continuous	Off	On	
Continuous	Off	Off	
Continuous	Off	On	

Table 3: TriggerSelector examples overview

An AcquisitionStart command sets *ExposureActive* to high. After this, the camera continues exposing with the maximum frame rate allowed. Maximum frame rate depends on factors, such as camera specifications and available bandwidth.

#### Acquisition without triggering

If no trigger is selected, the AcquisitionStart command starts exposure.




Figure 5: Acquisition without triggering

### TriggerSelector = FrameStart

#### *FrameStart* triggers the exposure.

AcquisitionMode = Continuous; TriggerSelector = AcquisitionStart; TriggerMode = Off; TriggerSelector = FrameStart; TriggerMode = On; AcquisitionStart (); FrameStart trigger ExposureActive ReadoutActive AcquisitionActive

Figure 6: TriggerSelector = FrameStart trigger



## AcquisitionMode

#### AcquisitionMode = SingleFrame


The AcquisitionStart command triggers the exposure of a single frame.


Every frame needs a separate AcquisitionStart command.

AcquisitionMode = SingleFrame;

TriggerSelector = AcquisitionStart; TriggerMode = Off;

> TriggerSelector = FrameStart; TriggerMode = Off;





*Figure 7: AcquisitionMode = SingleFrame* 

#### AcquisitionMode = MultiFrame

AcquisitionStart triggers exposure.

FrameCount sets the number of images.

AcquisitionMode = MultiFrame; FrameCount = 6;	
TriggerSelector = AcquisitionStart; TriggerMode = Off;	
TriggerSelector = FrameStart; TriggerMode = Off;	
ExposureMode = Timed;	
AcquisitionStart ();	
ExposureActive	
ReadoutActive	
AcquisitionActive	

*Figure 8: AcquisitionMode = MultiFrame* 



### ExposureMode

#### ExposureMode = Timed


FrameStart triggers exposure.

ExposureTime sets exposure time.

AcquisitionMode = Continuous;

TriggerSelector = AcquisitionStart; TriggerMode = Off;

> TriggerSelector = FrameStart TriggerMode = On;






Figure 9: ExposureMode = Timed



## ExposureMode = TriggerWidth

FrameStart triggers exposure.

The duration of the *FrameStart* trigger sets the exposure time.




Figure 10: ExposureMode = TriggerWidth



#### ExposureModes Mako U-503B


Mako U-503B provides only *Timed* value for ExposureMode.



#### TriggerWidth and TriggerActivation

If the frame or line TriggerActivation [TriggerSelector] is *LevelHigh*, the camera exposes as long as the trigger is high.

If TriggerActivation [TriggerSelector] is *LevelLow*, the camera exposes as long as the trigger is low.





## Contact us

## Website, email

**General** www.alliedvision.com/en/contact info@alliedvision.com

#### **Distribution partners**

www.alliedvision.com/en/avt-locations/avt-distributors

#### Support

www.alliedvision.com/en/support www.alliedvision.com/en/about-us/contact-us/technical-support-repair-/-rma

### Offices

# Europe, Middle East, and Africa (Headquarters)

Allied Vision Technologies GmbH Taschenweg 2a 07646 Stadtroda, Germany T// +49 36428 677-0 (Reception) T// +49 36428 677-230 (Sales) F// +49 36428 677-28

#### North, Central, and South America, Canada

Allied Vision Technologies Canada Inc. 300 – 4621 Canada Way Burnaby, BC V5G 4X8, Canada T// +1 604 875 8855

#### USA

Japan

Allied Vision Technologies, Inc. 102 Pickering Way- Suite 502 Exton, PA 19341, USA Toll-free// +1-877-USA-1394 T// +1 978 225 2030

## Asia-Pacific

#### China

Allied Vision Technologies Shanghai Co Ltd. B-510, Venture International Business Park 2679 Hechuan Road Minhang District, Shanghai 201103 People's Republic of China T// +86 21 64861133

#### Singapore

Allied Vision Technologies Asia Pte. Ltd 82 Playfair Rd, #07-01 D'Lithium Singapore 368001 T// +65 6634 9027

## Copyright and trademarks

All text, pictures, and graphics are protected by copyright and other laws protecting intellectual property. All content is subject to change without notice. All trademarks, logos, and brands cited in this document are property and/or copyright material of their respective owners. Use of these trademarks, logos, and brands does not imply endorsement. Copyright © 2024 Allied Vision Technologies GmbH. All rights reserved.

Allied Vision Technologies Yokohama Portside Bldg. 10F 8-1 Sakae-cho, Kanagawa-ku Yokohama-shi, Kanagawa, 221-0052

T// +81 (0) 45 577 9527